


Levelling bolt is used when the conveyor support is secured to the foundation in order to maintain parallelism of a base plate. It provides a fast and easy adjustment making your conveyor installation precise & efficient.

Levelling Procedure:

1. Loosen mounting bolts first
2. Levelling bolt can then be turned to provide the adjustments to the base plate*

*levelling bolt is not intended to be adjusted when conveyor is fully loaded.



REV

0

SH, Heavy Duty Support - Levelling Bolt

RoMASTER
CONVEYORS SINCE 1946